


● Direct adaptor and Mounting unit

Direct adaptor , DA

Direct adaptor is used to connect MMS directly with a contactor

Mounting unit , MU

This device is attached module to connect joined MMS with a contactor

· Application Model : MMS+ Susol, Metasol contactor(MC-9~95, MC-6a~100a), Mini contactor

Direct adaptor		Mounting unit	Combined devices	Applying Contactor
Frame	Name			
DA-16	DA-16SA	MU-45	MMS-32S + GMC-6M~16M	Mini-MC
	DA-16SD		MMS-32S + GMD-6M~16	
	DA-16HA		MMS-32H + GMC-6M~16M	
	DA-16HD		MMS-32H + GMD-6M~16M	
DA-18	DA-18SA		MMS-32S + MC-6a~18a	Metasol MC
	DA-18SD		MMS-32S + MC-6a~18a DC	
	DA-18HA		MMS-32H + MC-6a~18a	
	DA-18HD		MMS-32H + MC-6a~18a DC	
DA-22	DA-22SA		MMS-32S + MC-9b~22b	
	DA-22SD		MMS-32S + MC-9b~22b DC	
	DA-22HA		MMS-32H + MC-9b~22b	
	DA-22HD		MMS-32H + MC-9b~22b DC	
DA-32	DA-32SA		MMS-32S + MC-9~32(32a, 40a)	Susol, Metasol MC
	DA-32SD		MMS-32S + MC-9~32(32a, 40a) DC	
	DA-32HA		MMS-32H + MC-9~32(32a, 40a)	
	DA-32HD		MMS-32H + MC-9~32(32a, 40a) DC	
DA-63	DA-63A	MU-55	MMS-63AF + MC-35~63 (50a, 65a)	Susol, Metasol MC (Lug Type Only)
	DA-63D		MMS-63AF + MC-35~63 (50a, 65a) DC	
DA-95	DA-95A	MU-70	MMS-100AF + MC-65~95 (75a, 85a, 100a)	
	DA-95D		MMS-100AF + MC-65~95 (75a, 85a, 100a) DC	



Note) MMS and Contactor connected with Direct adaptor.